

---

# ATTI - PERFORMANCE CHECKLIST

---

## Field Technician

### AASHTO T19- Section 8 – Calibration of Measure

#### Calibration of Measure

- SEC 8: 8.2* Create a watertight seal with grease.
- SEC 8: 8.3* Weigh the measure and glass plate.
- SEC 8: 8.4* Fill measure with water that is at room temperature and cover with the glass plate in such a way to eliminate bubbles and excess water. Remove any water that overflowed.
- SEC 8: 8.5* Weigh the measure with water, and glass plate.
- SEC 8: 8.6* Measure the temperature to the nearest 1° F and determine the density.